



Iron Rock Off Road, Inc.

952-210-7185

Website: www.ironrockoffroad.com

E-mail: Contactus@ironrockoffroad.com

Jeep WJ Grand Cherokee 1999-2004 Premium Rock Slider Installation Instructions

1. Read and understand all installation instructions.
2. If you have any questions before, during, or after installation contact Iron Rock Off Road.
3. Ensure that all parts are present and in good condition.
 - Left Rock Slider (1)
 - Right Rock Slider (1)
 - 1/4 x 1" hex bolts (14)
 - 1/4" flat washer (14)
 - 1/4 x 1 1/4" self drilling screw (24)
4. For this installation you will need:
 - Pencil or fine tip marker, Floor Jack, 2 Jack Stands, Hand drill, Good quality 5/16" drill bit, 3/8" hex driver for hand drill, 7/16" socket and ratchet (or wrench), Touch up paint that matches your rocker panel.
5. On Laredo models remove the plastic rocker panel covers. You can trim them and re-install them after the installation if desired, otherwise just use the plastic tree rivets to fill the empty holes.
6. Locate the right side rock slider. Using a floor jack and/or 2 jack stands, position the rock slider against the rocker panel pinch weld on the right side (passenger's side) of the vehicle.
7. Center the rock slider front to rear, and position the height so that the pinch weld mounting screw holes can be seen from underneath the vehicle.
8. Very carefully mark the front to rear location of the mounting holes on the backside (inside) of the rocker panel pinch weld.
9. Transfer the marks to the front side (outside) of the rocker panel pinch weld.
10. Mark the vertical location of the rocker panel pinch weld mounting holes by measuring 3/8" down from the inside corner of the pinch weld where the rock slider will be installed.
11. Very carefully drill the rocker panel pinch weld mounting holes using a 5/16" drill bit. The location of your drilled holes must be as accurate as possible.
12. Remove any burrs caused by drilling.
13. Paint any exposed metal after drilling and deburring.
14. Remove the 2 screws that hold the front fender to the rocker panel where the rock slider will mount.
15. Place the rock slider in position and loosely install the 1/4" fine thread bolts and washers (not the self-drilling screws).
16. Use a floor jack to hold the rock slider up tightly into the corner of the rocker panel and tighten the mounting bolts.
17. Using the 1/4" self-drilling screws, fasten the unibody kickers to the unibody frame.
18. Stand back and admire your new rock slider from several viewing angles! 😊
19. Repeat the process for the left side of the vehicle.
20. Go out rock crawling and enjoy your new rocker panel protection and the peace of mind that is included free of charge.