

IRON ROCK OFF ROAD

JK Rear Bump Stop Spacer Instructions

1-877-919-JEEP www.ironrockoffroad.com

Parts Checklist:

- Instructions
- Iron Rock Off Road Decal (1)
- #199 JK Rear Bump Stop Spacer Hardware (2)**
 - 5/16-18 x 3/4 Serrated flange bolt, gr8 (2)
 - 5/16-18 Serrated flange nut (2)

Before you begin:

- ***Ensure that all parts are present and in good condition using shipping checklist. ***
- Read and understand all installation instructions.
- Tools required:
 - Sockets, wrenches, ratchet

Installation:

1. Place bump stop spacer on the bump stop pad on the rear axle with slant pointing forward.
2. Secure with 5/16 hardware, torque to 17 lb-ft.
3. Remove the rear springs and fully articulate the axle until the bump stops contact the bump stop spacer to ensure adequate clearance for all suspension components.

