

IRON ROCK OFF ROAD

WJ HD Coil Spring Retainer Kit
Installation Instructions

I-877-919-JEEP www.ironrockoffroad.com

Parts Checklist:

BOX 1 6x6x6

- Instructions
- Invoice
- Iron Rock Off Road Decal (1)

#39 - WJ Lower Coil Spring Retainers Hardware (1)

- WJ HD lower coil spring retainer tabs (2)
- 5/16" thread forming bolts (4)



Installation Instructions:

1. Be sure you have the following tools and supplies:
 - Floor jack and jack stands
 - Basic hand tools.
 - Hand drill and .272 diameter (letter I) drill bit
2. Lift front of vehicle and support with jack stands under the front axle.
3. Ensure the vehicle is safely supported.
4. Remove the front tires.
5. Disconnect the lower side (axle side) of the front shocks and move them out of the way.
6. The coil spring retainer attaches to the coil spring perch, just below the coil spring, in front of the shock absorber.
7. Hold the coil spring retainer down against the lowest coil of the coil spring and mark the location of the 2 mounting holes using a sharpie marker or scratch awl.
8. Drill both bolt holes using .272 diameter letter "I" drill bit.
9. Position the coil spring retainer and install the thread cutting bolts.
10. Re-install shock absorber.
11. Repeat for opposite side.
12. Install tires.
13. Lower vehicle from jack stands.
14. With the vehicle on the ground, torque any loose bolts to spec.

Final Safety Warning:

Re-torque all fasteners after 100 miles, and frequently inspect all safety critical suspension components. It is the responsibility of the installer to be sure all fasteners are properly tightened after installation and to ensure the owner knows his/her ongoing responsibility. It is the responsibility of the owner of the vehicle to be sure all safety critical components are inspected frequently, especially after off road or other demanding use.