

XJ Front Tow Hook System Installation:

Fits: 84-01 Jeep Cherokee XJ, 86-92 Jeep Comanche MJ



Iron Rock Off Road, Inc.

952-210-7185

Website: www.ironrockoffroad.com

E-mail: Contactus@ironrockoffroad.com



Shipping Checklist:

- Tow hook mount (1)
- Tow hook w/hardware 488605 (2)

Hardware Kit 50

- M10 x 30 cl10.9 hex bolt (2)
- 1/2 x 1-1/2 gr8 hex bolt (2)
- 1/2 gr8 hex nut (2)
- 3/8 USS washer (2)
- 1/2 USS washer (8)
- 1/2 gr8 split lock washer (2)

Before you begin:

1. Read and understand all installation instructions.
2. If you have any questions before, during, or after installation contact Iron Rock Off Road (see contact information above).
3. Ensure that all parts are present and in good condition per the above shipping checklist.
4. Remove front bumper.
5. Unbolt front sway bar from unibody.
6. Test fit a bolt in each of the rear mounting holes.
These are directly behind the sway bar bolt holes in the uniframe (toward the rear of the Jeep).
7. Re-tap the threads if needed using an M10 x 1.5 hand tap.
8. Loosely bolt tow hook mount in place using rear 3 bolts on each side, with the sway bar in place.
9. Verify tow hook mount is centered left to right and in proper position front to rear.
10. Tighten bolts enough to hold the tow hook mount firmly in place, but do not fully tighten at this time.
11. Using a hand drill with a 1/2" drill bit, drill the front 2 mounting holes into the uniframe. Peck drill and use plenty of oil.
12. Loosen the rear three bolts enough to insert one or two 1/2" flat washers between the uniframe and the tow hook mount's front hole on each side.
13. Install 1/2 x 1-1/2 bolts with a flat washer on each side and lockwasher and nut on top.
14. Tighten all bolts.
15. Install front bumper.
16. Trim plastic valence as needed for tow strap clearance. A sawzall or sharp utility knife work good for this purpose.
17. Enjoy!

