



### **Parts Checklist:**

- Instructions
- Iron Rock Off Road Decal (1)
- ZJ Fuel Tank Skid 82035 (1)

### **159 – ZJ Fuel Tank Skid Hardware (1)**

- M12 x 35 cl10.9 hex bolt (6)
- 1/2" USS washer (6)



## **Installation Instructions:**

### **Before you begin:**

- Read all safety warnings.
- Read and understand installation instructions.
- Contact Iron Rock Off Road with any questions before, during, or after installation.
- Ensure that all parts are present and in good condition using the included parts checklist.**
- Be sure you have the following tools and supplies:
  - Floor jack and jack stands
  - Basic hand tools
  - Anti-seize compound for bolts.

### **Fuel Tank Skid Installation:**

1. Lift rear of vehicle and support with tall jack stands under the unibody frame.
2. Ensure that vehicle is safely supported.
3. Remove receiver hitch if equipped.
4. Remove factory fuel tank skid plate if equipped.
5. Install new skid plate using provided hardware or re-use original nuts if your Jeep is equipped with studs.
6. Skid plate fits between fuel tank and factory exhaust heat shield.
7. Install receiver hitch if removed previously.
8. Verify adequate clearance around exhaust, wiring, cables, and anything else.
9. Tighten any loose bolts.
10. Lower vehicle.
11. Enjoy your new found sense of security!